



Technical Details

EXTERNAL SHELL: P.P. Polypropylene INTERNAL SHELL: HD Expanded polystyrene

HEADBAND: Soft PA Nylon

SIZE: Universal-adjustable from 53 to 63 cm

STANDARD: EN 397



350 a

-30°C / +50°C







WHE00023.202 YELLOW



WHE00023.204 RED



WHE00023.208 BLUE

Technology



VENTILATION: Maximum ventilation thanks to the eight air intakes. High breathability due to the volume of circulating air inside the helmet and the minimum contact surface with the head.



LAMP CLIPS: Provided with attachment for fitting lamp clips.



CHINSTRAP EN 397: Provided with attachment for fitting chinstrap EN 397.



SANITIZED®:The Sanitized® treatment is an antibacterial treatment that acts as an internal deodorant counteracting the development of unpleasant odors. Thanks to its hygienic function, it effectively prevents bacterial proliferation by increasing freshness and comfort of the fabric in contact with skin.



FAST 3DRY: High-tech 3D fabric that dries very quickly, helping the dispersion of moisture to the outside and leaving a pleasant feeling of freshness.



UP & DOWN 2.0: The innovative and exclusive UP & Down 2.0 technology ensures a precise and comfortable fit around the back of the head. The center wheel and the two side wings allow the quick adjustment of the helmet not only in width but also in height and tilt.



VISOR ATTACHMENT: Provided with attachment for fitting Zenith visors.



EARMUFFS FITTING: Provided with integrated slot for earmuffs with bayonet attachment. Compatible with KASK earmuffs.



Performances

PROTECTION AGAINST TOP IMPACTS	K 5 Kg da 2 m 100 J
PROTECTION AGAINST SIDE, FRONT AND REAR IMPACTS	K 5 Kg da 0,5 m 25 J
PROTECTION AGAINST THE PENETRATION OF OBJECTS	K 3 Kg da 1 m 30 J
LOWER TEMPERATURE RESISTANCE TEST	T= -30°C
PROTECTION AGAINST SIDE DEFORMATION- LD	K
PROTECTION AGAINST MOLTEN METAL SPLASHES- MM	K



K Standard requirements



(K)* Additional test in conformity with the requirements of the EN 12492



Optional requirements













Additional Information

GUARANTEE

3 years starting from the purchasing date.





10 years starting from the production date (production date is printed on a label contained on the inside of the helmet). Inspect the helmet regularly to check for any damage! Cuts, abrasions, deformation or changes in colour represent important elements for checking the helmet status.

CLEANING

Clean the helmet only with water, neutral pH soap and a soft, clean cloth. The inner lining should be washed by hand in cold water or in the washing machine (max 30°C - 85°F). Do not use chemical detergent or solvent.

STORAGE

When not in use the helmet should be stored away from direct sunlight or source of heat.

ADHESIVE APPLICATION

Do not apply adhesives, solvents, stickers or paint that do not comply with the manufacturer's specifications. Any alteration or intervention not provided for may impair its protective function.

Accessories



WVI00007 ZEN VISOR



WVI00012 ZEN FULL FACE



WVI0009/10 ZEN MESH VISOR



WAC00009 VISOR ADAPTOR



WAC00010 VISOR CARRIER



WI00011 ZEN PEAK



4 PIECES OF LAMP CLIPS



REPLACEMENT INNER PADDING





UPA00001



UAC00002



WAC00012 ZENITH CHINSTRAP EN 397

