



## Technical Details

EXTERNAL SHELL: P.P. Polypropylene INTERNAL SHELL: HD Expanded polystyrene

HEADBAND: Soft PA Nylon

SIZE: Universal-adjustable from 53 to 63 cm STANDARD: EN 397 – EN 50365 (Class 0)



350 g

-30°C / +50







WHE00022.202 YELLOW



WHE00022.204 RED



WHE00022.20

# Technology



**PROTECTION AGAINST ELECTRIC SHOCK:** Helmet provides protection against electrical hazards for use in the vicinity of low voltage systems with voltages up to 1500V DC or 1000V AC.



LAMP CLIPS: Helmet provided with slot for fitting lamp carrying clips.



CHINSTRAP EN 397: Provided with attachment for fitting chinstrap EN 397.



**SANITIZED®:** The Sanitized® treatment is an antibacterial treatment that acts as an internal deodorant counteracting the development of unpleasant odors. Thanks to its hygienic function, it effectively prevents bacterial proliferation by increasing comfort of the fabric in contact with skin.



FAST 3DRY: High-tech 3D fabric that dries very quickly, helping the dispersion of moisture to the outside and leaving a pleasant feeling.



**UP & DOWN 2.0:** The innovative and exclusive UP & Down 2.0 technology ensures a precise and comfortable fit around the back of the head. The center wheel and the two side wings allow the quick adjustment of the helmet not only in width but also in height and tilt.



VISOR ATTACHMENT: Provided with attachment for fitting Zenith visors.




EARMUFFS FITTING: Built with integrated slot for earmuffs. Compatible with KASK earmuffs.

FN

## Performances

PROTECTION AGAINST TOP IMPACTS	<b>K</b> 5 Kg da 2 m 100 J
PROTECTION AGAINST SIDE, FRONT AND REAR IMPACTS	<b>K</b> 5 Kg da 0,5 m 25 J
PROTECTION AGAINST THE PENETRATION OF OBJECTS	<b>K</b> 3 Kg da 1 m 30 J
PROTECTION AGAINST ELECTRIC SHOCK	K
LOWER TEMPERATURE RESISTANCE TEST	T= -30°C
PROTECTION AGAINST SIDE DEFORMATION- LD	K
PROTECTION AGAINST MOLTEN METAL SPLASHES- MM	K



 $oldsymbol{K}^\star$  Additional test in conformity with the requirements of the EN 12492

**K** Optional requirements













## Additional Information



3 years starting from the purchasing date.





10 years starting from the production date (production date is printed on a label contained on the inside of the helmet). Inspect the helmet regularly to check for any damage! Cuts, abrasions, deformation or changes in colour represent important elements for checking the helmet status.

### CLEANING

Clean the helmet only with water, neutral pH soap and a soft, clean cloth. The inner lining should be washed by hand in cold water or in the washing machine (max 30°C - 85°F). Do not use chemical detergent or solvent.

### **STORAGE**

When not in use the helmet should be stored away from direct sunlight or source of heat.

### ADHESIVE APPLICATION

Do not apply adhesives, solvents, stickers or paint that do not comply with the manufacturer's specifications. Any alteration or intervention not provided for may impair its protective function.

### Accessories



WVI00007 ZEN VISOR



WVI00012 ZEN FULL FACE



WVI0009/10 ZEN MESH VISOR



WAC00009 VISOR ADAPTOR



WAC00010 VISOR CARRIER



WI00011 ZEN PEAK



WAC00011 4 PIECES OF LAMP CLIPS



WPA00006 REPLACEMENT INNER PADDING



WHP00001



UPA00001 WINTER PADDING



UAC00002 HELMET BAG



WAC00012 ZENITH CHINSTRAP EN 397

